



Using the Chase Cutter

1. Wear your protective equipment including ear defenders, dust mask and goggles.
2. Switch off and remove the plug from the socket before making adjustments or fitting or changing the wheel.
3. Check that the cutting wheel is fitted correctly and that the guard is properly adjusted.
4. Always hold the chase cutter securely with both hands while working.
5. Make sure that the chase cutter is running at full speed before lowering it carefully onto the surface.
6. Be prepared for the reactive force when the wheel contacts the surface to be cut.
7. If the chase cutter starts to labour and slow down, do not force it so hard. Do not overload the machine.
8. The machine can only cut in straight lines. Do not try to go round corners.
9. Only use the machine up to shoulder height. Arrange a suitable working platform if you need to cut grooves higher than this.
10. Stop the chase cutter if someone approaches you.
11. Keep the cable clear of the cutting wheel.
12. If you think the cable may be cut or damaged in anyway, switch off and unplug at the socket before inspecting it. If the cable attached to the chase cutter is damaged, stop using the machine. Contact the hire company. If an extension cable has been damaged, do not use it again.
13. Take care not to accidentally pull the plug from the socket.
14. After switching off, wait for the wheel to stop completely before you put the machine down.
15. Switch off and remove the plug from the socket before leaving the cut-off saw unattended.
16. If your equipment does not work properly do not attempt to repair it. Contact the hire company.
17. You may want to read this leaflet again. Please keep it until you finish work.

Please store this leaflet safely. It may be required for further information



Hae
HIRE ASSOCIATION EUROPE

Hire Association Europe
2450 Regents Court
The Crescent
Birmingham Business Park
Solithull B37 7YE

Telephone: 44 (0) 121 380 4600
Fax: 44 (0) 121 333 4109
Email: mail@hae.org.uk
website: www.hae.org.uk

©Copyright Hire Association Europe April 2011

Any unauthorised reproduction – manually or electronically – is STRICTLY prohibited

Chase Cutter

The rules and procedures in force where people are at work may require the person responsible for this equipment to carry out a specific risk assessment.


It is important to read all of this leaflet BEFORE using the Chase Cutter

1. Plan your work and think ahead to make sure you will always be working safely.
2. Electricity is dangerous and must always be used with great care.
3. This chase cutter is designed to cut grooves in most building materials including brick, plaster and building blocks.
4. The action of this chase cutter can cause injury or damage if the machine is not used in a careful and controlled way.
5. If you have not used a chase cutter before, familiarise yourself with the machine on some straightforward work before you start on the main task.
6. You must have at least the following items of personal protective equipment: impact resistant goggles: EN166 – B or BS2092 grade 1; dust mask – a minimum of EN149 fp2(s) protection; ear muffs or plugs giving protection for levels up to 105 dB(A); gloves; rcd if using a 230 volt (mains) supply.
7. This chase cutter must not be used by minors, or by anyone under the influence of drugs or alcohol.
8. This chase cutter is designed for operation by an able bodied adult. Anyone with either temporary or permanent disability must seek expert advice before using it.



Every effort has been made by HAE/EHA to ensure that the information given in this document and supporting material is accurate and not misleading. HAE/EHA cannot accept responsibility for any loss or liability perceived to have arisen from the use of any such document/material. Only Acts of Parliament and Statutory Instruments have the force of law and only the courts can authoritatively interpret the law.

1. Lay the extension cable out carefully avoiding liquids, sharp edges, doorways or windows where it might be trapped, and unroll it fully or it will overheat and could catch fire.
2. Make sure that any extension cable connections are dry and safe.
3. If you need an extension cable, follow any special instructions given by the hire company. If the hire company have not given any special instructions, a suitably rated heavy duty one, not longer than 50 metres (160 feet). Plug it directly into the rcd.
4. Lay it out carefully avoiding liquids, sharp edges, doorways or windows where it might be trapped, and unroll it fully or it will overheat and could catch fire.
5. Make sure that any extension cable connections are dry and safe.



1. If you are using a portable transformer directly into the 230 volt socket. Do not use any 230V extension cables.
2. If you need to use an extension cable, follow any special instructions given by the hire company. If the hire company have not given any special instructions, a suitably rated heavy duty one, not longer than 50 metres (160 feet). You must only use an extension cable between the transformer and the machine.
3. If you need an extension cable, follow any special instructions given by the hire company. If the hire company have not given any special instructions, a suitably rated heavy duty one, not longer than 50 metres (160 feet). You must only use an extension cable between the transformer and the machine.
4. Lay it out carefully avoiding liquids, sharp edges, doorways or windows where it might be trapped, and unroll it fully or it will overheat and could catch fire.
5. Make sure that any extension cable connections are dry and safe.



Before Starting Work...

WORK AREA

1. Do not use this cut-off saw where there is a danger of explosion. It will ignite fumes from petrol, or gas cylinders.
2. Make sure that the area is clear and safe and that no-one is near to you or could distract you.
3. Protect other people from the noise and dust. Warn others to keep away.
4. Do not use this saw in the rain or where it might get wet.
5. Check that there are no hidden electric cables, gas or water pipes where you are going to cut.

OPERATORS

1. The following items of personal protective equipment (ppe) are the minimum that should be worn whenever you use this machine. Particular jobs or environments may require a higher level of protection. You must wear impact resistant goggles (EN166 – B or BS2092 grade 1) when you are working with this chase cutter.
2. This chase cutter is likely to cause noise levels up to 105 dB(A) – wear appropriate ear muffs or plugs giving hearing protection for this level as a minimum.
3. You will need to wear an appropriate dust mask (with a minimum of EN149 fp2(s) protection) when you are cutting material that causes dust.
4. Wear gloves and overalls to protect you from the dust.
5. Anybody who is working near to you will also need to wear appropriate personal protective equipment.
6. Check your chase cutter, cables, plugs and cutting wheels. If anything is found cutting wheels, ready to start work.
7. Switch off and remove the plug from the machine.
8. Do not fit the cutting wheel until you are at the work location, ready to start work.
9. If you are using a portable transformer directly into the 230 volt socket. Do not use any 230V extension cables.
10. If you need to use an extension cable, follow any special instructions given by the hire company. If the hire company have not given any special instructions, a suitably rated heavy duty one, not longer than 50 metres (160 feet). You must only use an extension cable between the transformer and the machine.
11. Lay it out carefully avoiding liquids, sharp edges, doorways or windows where it might be trapped, and unroll it fully or it will overheat and could catch fire.
12. Make sure that any extension cable connections are dry and safe.
13. If you need an extension cable, follow any special instructions given by the hire company. If the hire company have not given any special instructions, a suitably rated heavy duty one, not longer than 50 metres (160 feet). You must only use an extension cable between the transformer and the machine.
14. Lay it out carefully avoiding liquids, sharp edges, doorways or windows where it might be trapped, and unroll it fully or it will overheat and could catch fire.
15. Make sure that any extension cable connections are dry and safe.